

SUPERtrax

Licensed Mercedes Benz G63

Installation and Operation Instructions



Please read this instruction manual carefully. It is important to read and follow all the steps during assembly to ensure proper operation and safety of the child. Please keep this manual for future reference.




Scan to view the SUPERtrax
Assembly Video for the
Licensed Mercedes G63

SPECIFICATIONS:

Car Type:	Mercedes Benz G63
Battery Type:	12V14Ah
Electric Motor:	12V30W(Drive)
Age Range:	2 – 8 Years
Max. Weight:	225
Product Size:	
Avg. Speed:	2 – 4 MPH
Charging time:	8-12 hrs.
Avg. Use Time:	1-2 hrs. (depending on use)
Remote Battery:	2 - AAA (not included)

IMPORTANT!


<ul style="list-style-type: none"> Assembly of car and charging of battery is only to be done by an adult.  	<ul style="list-style-type: none"> WARNING!! NOT TO BE USED ON STREETS or IN TRAFFIC.
<ul style="list-style-type: none"> Never modify the electric circuit system or tamper with electric system. Can cause permanent damage. 	<ul style="list-style-type: none"> Please check the product regularly for any loose parts or wires to ensure proper operation.
<ul style="list-style-type: none"> Adult supervision is recommended during operation by child to avoid injury. Safety equipment is recommended. 	<ul style="list-style-type: none"> Please make sure that the child uses caution to avoid falls and collisions causing injury to the child or third party.
<ul style="list-style-type: none"> Do not pick up vehicle by steering wheel. 	<ul style="list-style-type: none"> Do not pick up battery by wires or charger.
<ul style="list-style-type: none"> Keep all plastic bags out of the reach of young children. 	<ul style="list-style-type: none"> Not recommended for children under the age of 2 yrs. due to small parts that could cause a choking hazard.
<ul style="list-style-type: none"> Battery must be charged for a minimum of 8-12 hours prior to first use of the car to avoid damage to the battery. Power switch must be in off position when charging. 	<ul style="list-style-type: none"> Battery charger should be examined for damage prior to each use. It is important to inspect the cord and both ends for damage. If damage is found, DO NOT USE THE CHARGER! Contact us for replacement charger.
<ul style="list-style-type: none"> Please retain instruction manual for future reference. 	<ul style="list-style-type: none"> Please retain packaging in the event it is necessary to return.

PARTS LIST:

1	Car Body	5	Remote Control
2	Wheels	6	Instruction Manual
3	Seat	7	Side View Mirrors
4	Steering Wheel	8	Charger


Adjustable Seat:

To adjust the seat, reach underneath and pull handle forward, you can then move the seat forward or back. Lock into place by releasing handle.



Working Hood:

For easy of replacing battery, the hood opens up and comes equipped with a rod to hold the hood piece open.




Assembly Instructions:

Car assembly should be done by adults. Make sure all small parts are kept out of reach from children. Children under the age of 36 months are prohibited from use. Please make sure you possess all parts before starting the assembly process.

*Dispose of plastic properly

Front Wheel Assembly:


Tip vehicle on its side, position the center of the front wheel with the front axle. Press the button in the center of the wheel to slide into place on the front axle. Repeat.



*This vehicle contains six motors


Rear Wheel Assembly:

With the vehicle tipped on its side, position one tire on the driver's side, and one on the passenger side on the same axle and push simultaneously. To complete installation ensure that the tires are secure by pressing the button in the center, repeat with both sets of rear tires.




Seat Assembly:

Align the seat slides with the car body. Push the seat back until the holes are aligned and screw into place.




Connecting the Steering Wheel:

Connect the steering wheel wire to the wires coming out of the steering column. Insert the steering wheel into the steering column until the pins are in place. Cannot be adjusted.




Mirror Assembly:

Remove the film on the mirror before assembly, then push the mirrors into place. Make sure they are secure.



Battery Connection:

Pop open the hood of the vehicle and use support rod to hold open the hood. To connect the battery to the vehicle connect the two clips together.



*This step may already be completed as we test our vehicles before they are shipped out.

Self-Resetting Circuit Breaker:


This car has an auto-reset circuit breaker. If the car stops suddenly during operation, it is likely due to an instantaneous and excessive current, causing the fuse to trip. If this occurs, simply stop vehicle operation for 30-60 seconds. To avoid the fuse tripping and power being cut off, please keep the following in mind:

- Do not overload the vehicle; the maximum load is 225 pounds.
- Do not drag, pull, tow or haul anything in or behind the vehicle.
- Do not allow water or any other liquids to contact the battery or any other electrical component on the vehicle.
- Do not change the circuit system or attempt to rebuild or reassemble the electrical structure of the vehicle.


Charging the battery:

The charging port is located on the right side of the dashboard. Plug the charger into the charging port first, then plug the charger into wall outlet. **BATTERY MUST BE CHARGED FOR A MINIMUM OF 12 HOURS BEFORE INITIAL USE TO AVOID DAMAGE TO THE BATTERY.**

Once battery is fully charged, disconnect from charger. Depress power button to turn on the car. Once power is on, all lights light up, accompanied by the sound of the engine.



Replacement Fuse for Battery: If the fuse is broken or burned out, there is a spare fuse in the fuse box located under the seat or behind the body of the car. Replace it and restart the car.



Please Note: As a safety precaution and to avoid damage to the charger, the car will not power up while charger port is plugged into the car.


Remote Control Instructions:

For the first time use of remote control or after replacing the battery, you need to sync the remote to the car.

1. Press and hold the car select button until the remote indicator light starts to flash
2. Then turn on the car and the remote indicator light should turn off. This means the car and remote are now paired.


If the blinking does not stop, repeat the steps.

This remote is equipped with soft start technology.



Usage Instructions

1. Before use make sure the battery is connected correctly and vehicle has been charged.
2. Make sure the seat is screwed down and in place
3. Before use make sure that the seatbelt is fastened and ready for use.



WARNING:

- Use only the rechargeable battery and charger supplied with your vehicle. **NEVER** substitute the battery or charger with another brand. Using another battery or charger may cause damage.
- **NEVER** modify the electric circuit system. Tampering with the electric system may cause permanent damage to the system.
- Do not allow direct contact between battery terminals.
- Do not allow any type of liquid on the battery or its components.
- Charge the battery in a well-ventilated area **ONLY**. Do not charge near or around flammable materials.
- **NEVER** pick up the battery by the wires or charger. Damage can occur to the battery and may cause a fire. Pick up the battery by the case **ONLY**.
- Charge the battery in a dry area **ONLY**. Wash hands after handling.
- Do not open the battery. Battery contains lead acid and other materials that are toxic and corrosive.
- Do not open the charger. Exposed wiring and circuitry inside case could cause electric shock. **NEVER** allow a child to handle or charge the battery. Battery is heavy and contains lead acid (electrolyte).
- Do not drop the battery. Permanent damage to the battery could occur or cause serious injury. Before charging the battery, check for wear or damage to the battery, charger, its supply cord and the connectors. **DO NOT** charge the battery if any damage to parts has occurred.
- Do not allow the battery to drain completely. Recharge the battery after each use or once per month if not used regularly.
- Do not charge the battery upside down.
- Always secure the battery with the bracket. Battery can fall out and injure a child if vehicle tips over.
- The Power Switch must be turned in the **OFF** position when charging.
- When the car begins to run slowly, recharge the battery.

GENERAL MAINTENANCE:

It is the parent's responsibility to check main parts of the toy before using. Regularly examine the car for potential hazard, such as damage to the battery, charger, cable or cord, and plug. Also, check that all screws are tightened throughout the car. In the event of such damage, the toy must not be used until that damage is repaired or replaced.

- Make sure the plastic parts of the vehicle are not cracked or broken.
- Occasionally use a lightweight oil to lubricate moving parts such as wheels.
- Park the vehicle indoors or cover it with a tarp to protect it from wet weather.
- Keep the vehicle away from sources of heat, such as stoves and heaters. Plastic parts may melt.
- Recharge the battery after each use. Only an adult should handle the battery. Recharge the battery at least once a month when not being used.
- Do not wash the vehicle with a hose. Do not wash the vehicle with soap and water. Do not drive the vehicle in rainy or snowy weather as water will damage the motor, electric system and battery.
- Clean the vehicle with a soft, dry cloth. To restore shine to plastic parts, use a non-wax furniture polish. Do not use car wax. Do not use abrasive cleaners.
- Do not drive the vehicle in loose dirt, sand or fine gravel which could damage moving parts, motors or the electric system.
- For extended times when the car will not be used, the power switch needs to be in the off position and the electrical connections should be disconnected from the battery.

TROUBLESHOOTING GUIDE:

Problem	Possible Cause	Possible Solutions
Car will not move	<ol style="list-style-type: none"> 1. Battery voltage is low. 2. Battery connector or wires are loose. 3. Battery is damaged or dead. 4. Electrical box or motor is damaged 	Charge the battery Re-connect the battery connector to the car Replace battery Replace motor
The battery will not charge.	<ol style="list-style-type: none"> 1. Battery connector may have come apart or have a bad connection. 2. Battery charger plugged into a bad wall outlet. 3. Battery charger is damaged. 	Re-connect the battery connector to the car electrical connector Try another wall outlet Replace battery charger
Shortened battery life	Battery was not charged fully Battery is old	Charge battery fully Change battery
Some Noise and heat when charging battery	Chemical reaction	Normal
Low Speed	Battery is old Battery is low on charge Weight limit exceeded Uneven or uphill path Vehicle is being used in harsh conditions	Change the battery Charge the battery Do not exceed max weight limit Use on flat surfaces Avoid using car in harsh conditions
Noise coming from motor/gearbox	Gear in motor/gearbox broken	Call for replacement motor
The car shakes when moving	Bad Connection of the motor wires Possible motor failure	Reconnect wires Call for replacement motor
Car needs a push to go forward	Poor contact of wires and/or connectors "Dead Spot" on motor	Check that the battery connectors are firmly plugged into each other. If wires are loose around the motor, contact the distributor's service department A dead spot means the electric power is not being delivered to the terminal connection. Call our service department

If you are unable to solve a problem, please feel free to contact us.

Phone: 402-477-0541 or Email:

customerservice@rollinghillstrading.com